Uses 1 "AAA" battery (included) 5872-9

Taylor thermometers and timers are the secret to cooking great meals. You can spend a lot on cookware and appliances, but a simple Taylor thermometer or timer brings it all together for great results. Since 1851 Taylor has provided you with accurate and easy to use instruments. When it comes to food safety and accuracy in measurement, it's no wonder that Taylor is the tool that chefs trust.

TO SET CLOCK:

1. Press the "12/24" button on the back of the timer to select a 12 or 24 hour clock ("AM" or "PM" icon = 12 hour clock, no icon = 24 hour clock).
2. Press 'H' to set hours. Press 'M' to set minutes. Press 'S' to reset seconds to zero. Hold down the buttons to advance the digits quickly.
3. Press 'CLOCK'. The clock is set.

TO PROGRAM TIMER #1:

1. Press 'T1'. The 'TIMER 1' icon will flash.
2. Press 'H' to set hours, 'M' to set minutes, and 'S' to set seconds. Hold down the buttons to advance the digits quickly. To start over, press 'CLEAR'.
3. Press 'START/STOP' to start timer countdown. Press again to pause or resume countdown.
4. At "00:00", the alarm will beep and a "TIME'S UP" icon will flash. The timer will begin to count up. Press 'START/STOP' to stop alarm and pause timer. Press "CLEAR" to reset to zero.

TO PROGRAM TIMER #2:

1. Press 'T2'. The 'TIMER 2' icon will flash.
2. Follow timer setting instructions as listed under Timer #1.
3. To view the clock during Timer #2 countdown, press 'CLOCK'. The timer will continue to operate. Press 'T2' again to view Timer #2 countdown.
4. When both timers are in use, press 'T1/2' to view both timers. A flashing 'TIMER 1' or 'TIMER 2' icon indicates which timer is active.

NOTE: a timer must be active for the button to work; for example, TIMER 1 must be active before its alarm can be turned off.

5. Each timer will time up to 23 hours, 59 minutes and 59 seconds.

MEMORY FEATURE:

This timer will store the last countdown time in memory.

1. Press 'TI' or 'T2' to select a timer. Program time.
2. Press 'MEMORY' on back of timer to store the time. A "MEMORY" icon will appear. (Press 'CLEAR' to zero out any previously saved memory time, then reprogram time).
3. Press 'START/STOP' to begin timing.
4. When time is up, press 'START/STOP' to stop timer, then press 'CLEAR'.
5. Press 'MEMORY' to recall the last countdown time for the active timer.
6. Press 'CLEAR' while a timer is selected to reset memory time.

COUNT UP FEATURE:

Both timers will count up when timing is done. Timer 2 can also display a countup timer.

1. Press 'CLOCK' to display the current time and Timer
2. Press 'START/STOP' and Timer 2 will count up. Press 'START/STOP' again to pause or resume timing. Press 'CLEAR' while paused to reset timer.

CLEANING AND CARE:

Clean by hand. Do Not completely immerse timer in water or put into dishwasher.

NOTE: There is a static cling label over the digital display and a strip under the battery cover to prevent battery drain during shipping. Please remove both before use.

ONE YEAR LIMITED WARRANTY:

Taylor warrants this product to be free from defects in material or workmanship (excluding batteries), and on return, will repair or replace it at our option, without charge.

Taylor cares and is dedicated to the conservation of our natural resources. Please properly recycle this packaging.

TAYLOR®

Oak Brook, IL 60523

www.taylorusa.com

Made to our exact specifications in China.

5872-9
3313
V0270

0 77784 58729 4

©2011 Taylor Precision Products and its affiliated companies, all rights reserved. Taylor® is registered trademark of Taylor Precision Products and its affiliated companies. All rights reserved.

CP58729 5.11